

direction for using:

- 1.The working voltage of the product is AC100V-265V 50/60Hz. Do not exceed the working voltage range.
- 2.As the cover of the light is made of glass, and the glass is fragile, Please pay attention to gently take the light to release the pressure while transportation, handle, storage, fix.

Installation instructions:

1. When installing lamps and lanterns, the wiring and wiring place shall be sealed to prevent electric leakage. Do not electrify during wiring.
- 2.When external power lines are connected, corresponding waterproof and leakage prevention measures must be taken.
- 3.It shall not violate any fire regulations when used the lamp.
- 4.Please employ a professional electrician to install it. The cable should be 0.75-1mm three-core cable ,the brown wire is " L" wire, the blue wire is "N" wire, and the yellow-green wire is the "PE".)

Installation diagram:

